

40MM GOST to
40MM STANAG
ADAPTER INSTRUCTIONS

INSTALLATION

STEP 1:

With filter in one hand, and mask in the other, screw filter adapter into mask.



STEP 2:

Screw STANAG filter into GOST adapter. Do not over-torque, allow filter to seal on gasket.



STEP 3:

With gas mask on face, cover inhale valve to ensure a proper pressure seal.



**Installation
Complete**

INFORMATION

HEATH AND SAFETY REMINDER:

Gas masks are filtration devices. They are not positive pressure aparatuses and do not produce oxygen. Such PPE should not be used in the case of gas leaks, chemical spills, or anyplace where simple asphyxiant's are in a high concentration.

GENERAL LIABILITY STATEMENT:

The producer of this product accepts no liability in cases where the product has been used inappropriately or not as intended. The selection and use of the product are the exclusive responsibility of the individual operator.

PRODUCT CARE:

Gas masks and their components are suseptible to degridation from sunlight. Do not leave this product exposed to direct sunlight for prolonged periods. When not in use, keep adapter and mask stored in the recommended protective bag.

QC INFORMATION:

PRODUCED ON: BY: FOR:

	/		/		1	K
--	---	--	---	--	---	---



NOS EXA GROUP

DRIVING INNOVATION

NOS-EXA.GROUP/